

SENSORIA

DINING CHAIR



SENSORIA DINING CHAIR

Designer	George Tsironas
Dimensions	W51 x D51 x H82 - SH46 cm
Materials	Powder coated aluminum frame Wooven cord Ø5 Seat and cushion upholstered in fabric or eco leather
Weight	4.65 kg
Volume	0.21 m³



Sustainability

10DEKA prioritizes its ecological footprint by using recyclable materials and manufacturing practices to minimize the waste and the energy consumption, while continuously expanding the range of eco-friendly products. Our stringent adherence to global standards ensures that our products meet rigorous criteria for strength, durability, and safety.

Warranty

10DEKA offers a 2-year warranty on its products, valid ONLY with proper use. It excludes faults from normal wear and tear. If a manufacturing defect is found, the company will decide to repair or replace the product. For more information, please reach out to our sales team.



SENSORIA DINING CHAIR

Fabrics

			
F11 Coco 8001	F12 Grafito 8013	F13 Lino 8008	F14 Marfin 3741
			
F16 Perla 3735	F19 Brisa Blue 3736	F20 Brisa Grey 3730	F28 Brisa 8011
			
F29 Optic 3934	F32 Aqua 8006	F39 Mineral 1442	F92 Umbra 20203
			
F93 Nectar 20200	F94 Scarlet 3947	F95 Apio 20201	F96 Gris Porcelana 20099
			
F97 Salvia 20081	F98 Fossil 3659	F99 Alga 3667	F100 Stone Grey 3669
			
F127 Ash Grey PVC	F128 Greige PVC	F26 Clara 3950	F76 Mostaza 1732
			
F77 Integral 1734	F78 Piedra 1730	F84 Avera 1712	F85 Gris 1714
			
F87 Stone 1709	F88 Brisa 1706	F101 Musgo 1701	F102 Mostaza 1713
			
F103 Ice 20234	F104 Albero 20238	F105 Fresh 20239	F106 Copper 20240
			
F107 Denim 20242	F113 Terra Stripes 00	F114 Sand Stripes 96	F115 Denim Stripes 98
			
F116 Terra Pinstripes 18	F117 Sand Pinstripes 14	F118 Denim Pinstripes 16	

Maintenance


Regularly vacuum your furniture using the upholstery nozzle to remove dust and prevent fluff and pilling. Occasionally, straighten the fabric with your hands. To smooth out wrinkles, use a steamer. If liquids spill, immediately blot the area with an absorbent napkin or cloth, dabbing gently towards the center of the stain. Avoid using concentrated detergents, bleach, ammonia, optical brighteners, or soaps meant for hard surfaces. Spot cleaning is not recommended as it can damage the fabric and cause color loss. For wool fabrics, most stains can be removed with lukewarm water and a clean, lint-free cloth. If needed, add a small amount of neutral detergent. Do not rub the material vigorously, as this can cause color loss and fabric damage. Using a hairdryer may help to prevent water marks. If a stain persists, consult a professional cleaner.

SENSORIA DINING CHAIR

Fabrics



F89 Gris 1742



F90 Glacier 1740



F91 Grafito 1739

F111 Ottoman
Apio 20069F112 Ottoman
Umbra 20071

F119 Sky 01



F120 Sky 22



F121 Sky 03



F122 Sky 07



F123 Sky 11



F124 Sky 23




F125 Sky 20



F126 Sky 21

F108 Papyrus
20246F109 Grey Sand
20247

F110 Optik 20245

CLI B123 Obvious
CliffCLI B126 Slate
CliffCLI B128 Jacket
CliffCLI B129 Petra
CliffCLI B131 Fir
CliffLOP2 R079 Bud
LopiLOP2 R081 Fawn
LopiLOP2 R082 Pepper
LopiLOP2 R085 Viper
LopiLOP2 R086 Fossil
LopiSLO 19011 Farafra
SlowSLO 19103 Alezan
SlowSLO 19106 Fern
SlowSLO 19107 Spirea
Slow

Eco Leather



L1 Beige



L2 Beige Olive



L3 Ivory



L4 White



L5 Blue



L6 Graphite




L7 Light Grey



L21 Ebony



L22 Ash




L23 Ice



L24 Ocean



L25 Pearl



L26 Shark



L27 Terracotta




L28 Toffee



L29 Walnut

SENSORIA DINING CHAIR

Frame Colors

			
White	Sabbia	Beige	Dark Brown
			
Light Grey	Cloud Grey	Graphite	Turquoise Blue
			
Royal Blue	Denim Blue	Olive Green	Saumon Orange
			
Rouge Beige	Rouge Royal	Tanami Red	Brown Amber

Cords-Sensoria/Curacao/Aurora

			
Pastel Turquoise	Basalt Grey	Grey	Brown
			
Terracotta			