

SENSORIA

LOUNGE ARMCHAIR (WITH WOODEN ARMRESTS)



SENSORIA LOUNGE ARMCHAIR (WITH WOODEN ARMRESTS)

Designer	George Tsironas
Dimensions	W77 x D72 x H78 - SH41 cm
Materials	Powder coated aluminum frame Armrests in tropical wood Wooven cord Ø5 Seat and cushion upholstered in fabric or eco leather
Weight	7.65 kg
Volume	0.43 m ³



Sustainability

10DEKA prioritizes its ecological footprint by using recyclable materials and manufacturing practices to minimize the waste and the energy consumption, while continuously expanding the range of eco-friendly products. Our stringent adherence to global standards ensures that our products meet rigorous criteria for strength, durability, and safety.

Warranty

10DEKA offers a 2-year warranty on its products, valid ONLY with proper use. It excludes faults from normal wear and tear. If a manufacturing defect is found, the company will decide to repair or replace the product. For more information, please reach out to our sales team.



SENSORIA LOUNGE ARMCHAIR (WITH WOODEN ARMRESTS)

Fabrics



F11 Coco 8001



F12 Grafito 8013



F13 Lino 8008



F14 Marfin 3741



F16 Perla 3735

F19 Brisa Blue
3736F20 Brisa Grey
3730

F28 Brisa 8011



F29 Optic 3934



F32 Aqua 8006



F39 Mineral 1442

F92 Umbra
20203F93 Nectar
20200F94 Scarlet
3947

F95 Apio 20201

F96 Gris
Porcelana 20099

F97 Salvia 20081



F98 Fossil 3659



F99 Alga 3667

F100 Stone Grey
3669F127 Ash Grey
PVC

F128 Greige PVC



F26 Clara 3950

F76 Mostaza
1732

F77 Integral 1734



F78 Piedra 1730



F84 Avera 1712



F85 Gris 1714



F87 Stone 1709



F88 Brisa 1706



F101 Musgo 1701

F102 Mostaza
1713

F103 Ice 20234



F104 Alberio
20238F105 Fresh
20239F106 Copper
20240F107 Denim
20242F113 Terra Stripes
00F114 Sand Stripes
96F115 Denim
Stripes 98F116 Terra
Pinstripes 18F117 Sand
Pinstripes 14F118 Denim
Pinstripes 16

Maintenance


Regularly vacuum your furniture using the upholstery nozzle to remove dust and prevent fluff and pilling. Occasionally, straighten the fabric with your hands. To smooth out wrinkles, use a steamer. If liquids spill, immediately blot the area with an absorbent napkin or cloth, dabbing gently towards the center of the stain. Avoid using concentrated detergents, bleach, ammonia, optical brighteners, or soaps meant for hard surfaces. Spot cleaning is not recommended as it can damage the fabric and cause color loss. For wool fabrics, most stains can be removed with lukewarm water and a clean, lint-free cloth. If needed, add a small amount of neutral detergent. Do not rub the material vigorously, as this can cause color loss and fabric damage. Using a hairdryer may help to prevent water marks. If a stain persists, consult a professional cleaner.

SENSORIA LOUNGE ARMCHAIR (WITH WOODEN ARMRESTS)

Fabrics

			
F89 Gris 1742	F90 Glacier 1740	F91 Grafito 1739	F111 Ottoman Apio 20069
			
F112 Ottoman Umbra 20071	F119 Sky 01	F120 Sky 22	F121 Sky 03
			
F122 Sky 07	F123 Sky 11	F124 Sky 23	F125 Sky 20
			
F126 Sky 21	F108 Papyrus 20246	F109 Grey Sand 20247	F110 Optik 20245
			
CLI B123 Obvious Cliff	CLI B126 Slate Cliff	CLI B128 Jacket Cliff	CLI B129 Petra Cliff
			
CLI B131 Fir Cliff	LOP2 R079 Bud Lopi	LOP2 R081 Fawn Lopi	LOP2 R082 Pepper Lopi
			
LOP2 R085 Viper Lopi	LOP2 R086 Fossil Lopi	SLO 19011 Farafra Slow	SLO 19103 Alezan Slow
			
SLO 19106 Fern Slow	SLO 19107 Spirea Slow		

Eco Leather

			
L1 Beige	L2 Beige Olive	L3 Ivory	L4 White
			
L5 Blue	L6 Graphite	L7 Light Grey	L21 Ebony
			
L22 Ash	L23 Ice	L24 Ocean	L25 Pearl
			
L26 Shark	L27 Terracotta	L28 Toffee	L29 Walnut

SENSORIA LOUNGE ARMCHAIR (WITH WOODEN ARMRESTS)

Frame Colors



White

Sabbia

Beige

Dark Brown



Light Grey

Cloud Grey

Graphite

Turquoise Blue



Royal Blue

Denim Blue

Olive Green

Saumon Orange




Rouge Beige

Rouge Royal

Tanami Red

Brown Amber

Cords-Sensoria/Curacao/Aurora



Pastel Turquoise

Basalt Grey

Grey

Brown



Terracotta

Wood Finishes



Teak

Iroko

Vintage Grey